

VPU2 Variable Air Volume Package Unit Controller

Self-Contained Interoperable Controller Model UCP-1

SUPERSEDES: April 17, 2013

EFFECTIVE: April 2, 2015

Plant ID: 001-3958

SPECIFICATIONS

Electrical Inputs

Cabling: twisted shielded pair, 18 AWG recommended—500 feet max. (152 meters), 10 bit resolution

Mixed Low Limit, Filter Status, Smoke Detect, Local IAQ Alarm: Dry Contact, Normally Open, 5 Volts DC Max

Fan Proof: Dry Contact, Normally Closed, 5 Volts DC Max

Return Air Humidity, Static Pressure: 0 - 10 Volts DC

Mixed Air Temperature, Supply Air Temperature, Return Air Temperature: Precon Type III 10K thermistor

Electrical Outputs

Cooling Stages 1, 2, 3, & 4; Heating Stages 1 & 2; Fan Start/Stop; Two-position Economizer: 24 Volts AC, 1A @ 50C, 0.5A @ 60C, limited by the Class 2 supply rating

Modulated Heating, Modulated Cooling, Modulated Economizer, Modulated Static Pressure Fan: 0-10 Volts DC, 2K Ohm minimum load, 8 bit resolution

Recommended Sensor Wire

Cable Type	Pairs	Details	Taco Catalog No.
18AWG	1	Stranded Twisted Shielded Pair, Plenum	WIR-018

Recommended LON Bus FTT-10A Network Wire

Speed: 78KBPS

Max Volts: 42.4 Volts DC

Cabling: Maximum node-to-node distance: 1312 feet (400 meters); Maximum total distance: 1640 feet (500 meters)

Cable Type	Pairs	Details	Taco Catalog No.
Level 4 22AWG (0.65mm)	1	Unshielded, Plenum, U.L. Type CMP	WIR-022

Mechanical

Dimensions: 5.55" (141mm) high, 6.54" (166 mm) wide, 1.75" deep (44 mm), ABS

Controller Weight: 0.70 pounds (0.32 kilograms)

Shipping Weight: 1.0 pounds (0.46 kilograms)

Processor: 3150 Neuron 10 MHz

Flash: 48 Kilobytes

SRAM: 8 Kilobytes

Termination: 0.197" (5.0 mm) Pluggable Terminal Blocks, 14-22 AWG

Temperature: 32 °F to 140 °F (0 °C to 60 °C)

Humidity: 0 to 90%, non-condensing

UL Listed for US and Canada, Energy Management Equipment PAZX and PAZX7

FCC Part 15 Class A compliant

Equipment Location



Abide by all warnings regarding equipment location provided earlier in this document.

Optimally, the equipment should be installed within a secure enclosure.

The equipment must be installed indoors unless contained within a protective enclosure. The enclosure must maintain internal temperature and humidity within the ranges specified for this equipment.

The equipment must be installed within 500 feet of all input peripherals (smoke detectors, sensors, etc.) that will be connected to the equipment. It must be within 200 feet of any connected thermostats.

Selecting a Power Source

This equipment requires a UL recognized external power source (not supplied) to operate. The controller power input requires a voltage of 24 Volts AC.

To calculate power source current requirements, add the power consumption of all peripheral devices to that of the controller.

The controller and triac output loads can use the same power source. If both are using the same power source, the loads must have EMF protection. This protection can be integral to the load, or installed in the 24 VAC wiring across the load's coil.

To provide necessary RFI and transient protection, the controller's ground (GND) pin (T40) must be connected to earth ground or the earth ground of the packaged unit's enclosure ground. Failure to properly ground the controller may cause it to exceed FCC limits. Excessive noise could also produce inaccurate sensor data. The power source must be capable of operating with this connection to ground.

INSTALLATION PRECAUTIONS

General



CAUTION: This symbol is intended to alert the user to the presence of important installation and maintenance (servicing) instructions in the literature accompanying the equipment.



CAUTION: Risk of explosion if battery is replaced by an incorrect type. Contains lithium type battery; dispose of properly.



WARNING: Electrical shock hazard. Disconnect **ALL** power sources when installing or servicing this equipment to prevent electrical shock or equipment damage.

Make all wiring connections in accordance with these instructions and in accordance with pertinent national and local electrical codes. Use only copper conductors that are suitable for 167 °F (75 °C).

Static Electricity

Static charges produce voltages that can damage this equipment. Follow these static electricity precautions when handling this equipment.

- Work in a static free area.
- Touch a known, securely grounded object to discharge any charge you may have accumulated.
- Use a wrist strap when handling printed circuit boards. The strap must be secured to earth ground.

FCC Compliance

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference. This equipment can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to a power source different from that to which the receiver is connected.
- Consult the equipment supplier or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications to this equipment not expressly approved in these instructions could void your authority to operate this equipment in the United States.


INSTALLATION



Warning: Electrical shock hazard. To prevent electrical shock or equipment damage, disconnect **ALL** power sources to controllers and loads before installing or servicing this equipment or modifying any wiring.

Mounting the Device

1. Select a mounting location. Enclosure mounting is recommended.
2. Hold the controller on the panel you wish to mount it on. With a marker or pencil mark the mounting locations on the panel.
3. Using a small drill bit pre-drill the mounting holes.
4. Using two #6 pan head screws, mount the controller to the panel.
5. Wire the controller.

Figure 1: Mounting Dimensions

Grounding the Device



The ground terminal (T40) must be securely connected to earth ground. Failure to properly ground this equipment will result in improper operation. Improper grounding may also increase the risk of electrical shock and may increase the possibility of interference with radio/TV reception.




For best performance, connect the power supply common terminal (T38) to the same external point as the ground terminal (T40).

Power

Requires: 24VAC (20VAC to 28VAC), requires an external Class 2 supply

Consumes: 7.2W with no external loads, maximum limited by the Class 2 supply rating

This page left blank intentionally



Symbols:

- Duct Mount - 10K ohm Precon Type III thermistor
Taco Part #ACC-DS-8-10KP3-PB, ACC-DS12-10KP3-PB
- Duct Mount - 0-10VDC Humidity Transmitter
Taco Part #ACC-DHS3-10
- Duct Mount - Smoke Detector
Normally Open, Dry Contact Switch
- Duct Mount - 0-10VDC Air Differential Pressure Transmitter
Taco Part #ACC-ADPT-250WC (0-2.5"WC) or ACC-ADPT-5WC (0-5"WC)



- Duct Mount - Freeze Stat - Normally Open, Dry Contact Switch
- Duct Mount - Air Differential Pressure (Flow Proof) Switch
Normally Open, Dry Contact Switch, Taco Part #ACC-ADPS-12WC
- Duct Mount - 0-10VDC CO₂ Transmitter
Taco Part #ACC-DS-CO₂


Wire Types:

- Line Voltage
- 24VAC Low Voltage
- Echelon Approved Level IV Cable
2-Wire, Twisted Pair, Non-shielded
Taco Part #WIR-022
- 2-Wire Low Voltage, Shielded Cable
Shield Grounded, Taco Part #WIR-018
- 10K Ohm 1/4 or 1/2 Watt Resistor
- Wire Jumper

Variable Air Volume (VAV) Staged Rooftop or Split System Up to:

- 2 Stage Heating – Electric or Gas
- 4 Stage Cooling – DX
- Fan Variable Frequency Drive
- Modulating or 2-pos. Economizer
- Demand Controlled Ventilation (CO²)

Can be integrated with up to 56 Taco VAV Controllers on Taco LON Bus



VPU2 - VARIABLE AIR VOLUME STAGED ROOFTOP OR SPLIT SYSTEM

Controlled: 2 stage heating (electric or gas), 4 stage cooling (DX), Fan Variable Frequency Drive

Sensors Required: Supply Air Temp, Fan Proof, Filter Status, Air Differential Pressure Transmitter

NOTE: Instructions below assume at least 1 VAVD (up to 56) on Taco LON Bus. If none, skip steps 3 through 6.

Setup Instructions

1. Press **Controllers** from main screen.
2. Select required VPU from controller list and press appropriate controller.

Controllers	15:36	PREV	HOME
ASM	OAT: 60.1°F Meter: 0 KWH		
BLMC	Demand System 0.00 %		
BZU2	Zones On: None		
BZU2-1	Zones On: None		
CCU	Sup.: 47.6°F Ret.: 59.6°F		
MPU2	Temp: 59.4°F Setp: 100.0°F		
DXU3	Temp: 78.3°F Setp: 71.0°F		
VPU	Temp: 59.8°F Setp: 55.0°F		
DXU4	Temp: 78.2°F Setp: 156.2°F		

3. Press **HVAC Setup**.

Edit Controller	15:36	PREV	HOME
Save	Delete	Replace	Details
Upgrade	Reset		
Name VPU			
All Settings	Inputs	Outputs	Alarms
Subsystem Status	HVAC Setup	Reset Runtimes	

4. The *HVAC Setup* menu opens. Press **Zone Members**.

VPU HVAC Setup	15:37	PREV	HOME
Backup Schedule	Runtimes And Limits	Optimum Start	Zone Members
Zone Reference			

5. The *Zone Members* menu opens.

6. Press on VAV boxes associated with MPU. Associated controllers show in RED afterward. Press **Save**.

VPU Zone Members	15:38	Save	PREV	HOME
VAVI	Master: VPU			
VAVD	Associated to : MPU2			
VAVI	Master: VPU			
VAVD	Associated to : MPU2			
VAVI	Not associated			

7. Press **Prev.** twice. From the main controller menu, press **All Settings**.

Edit Controller	15:38	PREV	HOME
Save	Delete	Replace	Details
Upgrade	Reset		
Name VPU			
All Settings	Inputs	Outputs	Alarms
Subsystem Status	HVAC Setup	Reset Runtimes	

8. Press **Setpoints**.

VPU Settings	15:01	Paste	PREV	HOME
Commissioning				More...
Setpoints				More...
MPU2 Setpoints				More...
MPU2 Setpoints	15:03	Save	PREV	HOME

Cooling Setpoint	55.0	°F
Heating Setpoint	80.0	°F
Supply Cool Limit	10.0	°F
Supply Heat Limit	5.0	°F

9. The *Setpoint* menu opens.
 - a. Specify **Cooling Setpoint**.
 - b. Specify **Heating Setpoint**.
 - c. Specify **Supply Cool Limit** (sets deviation from setpoint for alarm).

- d. Specify **Supply Heat Limit** (sets deviation from setpoint for alarm).
 e. Press **Save**.
 10. Press **Supply Temp Reset Curve**.

VPV Settings	15:01	Paste	PREV	HOME
Commissioning			More...	
Setpoints			More...	
Supply Temp Reset Curve			More...	
Pressure Settings			More...	
MPU2 Supply Temp Reset Curve	15:06	Save	PREV	HOME
Min Differential	0.0	°F		
Max Differential	5.0	°F		
Cool Setp Low	45.0	°F		
Cool Setp High	55.0	°F		
Heat Setp Low	80.0	°F		
Heat Setp High	100.0	°F		
Next 14			Bottom	

11. The *Supply Temp Reset Curve* menu opens.

- a. Specify **Min Differential**.
 b. Specify **Max Differential**.
 c. Specify **Cool Setp Low**.
 d. Specify **Cool Setp High**.
 e. Specify **Heat Setp Low**.
 f. Specify **Heat Setp High**.
 g. Press **Save**.
 12. Press **Pressure Settings**.

VPV Settings	16:14	Paste	PREV	HOME
Commissioning			More...	
Setpoints			More...	
Supply Temp Reset Curve			More...	
Pressure Settings			More...	
VPV Pressure Settings	09:44	Save	PREV	HOME
Setpoint	1.80	WC		
IAQ Setpoint	1.50	WC		
Kp	5.00	%		
Ki	0.05	%		
Minimum Output	0.0	V		
Maximum Output	10.0	V		
Press Min	2.00	WC		
Press Max	5.00	WC		
Soft Start Rate	0.00	%		

13. The *Pressure Settings* menu opens.
 a. Specify **Static Pressure Setpoint** in Inches of WC.
 b. Specify the **IAQ Setpoint** (if applicable).

- c. Specify **Min Output Voltage** (VDC) for VFD Drive (commonly 0-2VDC).
- d. Specify **Max Output Voltage** (VDC) for VFD drive (commonly 10VDC).
- e. Specify **Press Min** (Static pressure to report when the Duct SP sensor provides 0 VDC).
- f. Specify **Press Max** (Static pressure to report when the Duct SP sensor provides 10 VDC).
- g. Specify **Soft Start Rate**. Setting the soft start ramp rate to 0% per second or 100% per second disables soft start ramping. Soft start ramp rate slows initial fan start rate to protect equipment and ductwork.
- h. Press **Save**.

NOTE: DO NOT change factory KP/KI settings. Please review Factory KP/KI Setting White Paper # 508-001.

14. Press **Staged Cooling**.

VPU Settings	16:14	Paste	PREV	HOME
Commissioning			More...	
Setpoints			More...	
Supply Temp Reset Curve			More...	
Pressure Settings			More...	
Staged Cooling			More...	
VPU Staged Cooling	10:02	Save	PREV	HOME
Stages	<input type="text" value="4"/>			
Control band	<input type="text" value="1.0"/> °F			
Stage time	<input type="text" value="5"/> Min			
Floating SP Heating			More...	
Next 10			Bottom	

15. The *Staged Cooling* menu opens.

- a. Specify number of **Stages** of equipment (0-4).
- b. Specify the stage **Control Band** in degrees. Cannot be set to 0.
- c. Specify the **Stage Time** in minutes. Cannot be set to 0.
- d. Press **Save**.

16. Press **Staged Heating**.

VPU Settings	16:14	Paste	PREV	HOME
Commissioning			More...	
Setpoints			More...	
Supply Temp Reset Curve			More...	
VPU Staged Heating	10:05	Save	PREV	HOME
Stages	<input type="text" value="2"/>			
Control Band	<input type="text" value="1.0"/> °F			
Stage Time	<input type="text" value="5"/> Min			
Staged Heating			More...	
Modulated Heating			More...	
Floating SP Heating			More...	
Next 10			Bottom	

17. The **Staged Heating** menu opens.

- Specify number of **Stages** of equipment (0-2).
- Specify the stage **Control Band** in degrees. Cannot be set to 0.
- Specify the **Stage Time** in minutes. Cannot be set to 0.
- Press **Save**.

18. Press **Next 10**.


VPU Settings	16:14	Paste	PREV	HOME
Commissioning				More...
Setpoints				More...
Supply Temp Reset Curve				More...
Pressure Settings				More...
Staged Cooling				More...
Modulated Cooling				More...
Floating SP Cooling				More...
Staged Heating				More...
Modulated Heating				More...
Floating SP Heating				More...
Next 10				Bottom

19. Press **Economizer**.

VPU Settings	16:14	Paste	PREV	HOME
Prev 10				Top
Economizer				More...
VPU Economizer	10:09	Save	PREV	HOME
Type	Disabled ▾			
Setpoint	55.0 °F			
Min fresh air	10.00 %			
Kp	5.00 %			
Ki	0.05 %			
Min AO voltage	0.0 V			
Max AO voltage	10.0 V			
IAQ Sensor				More...
Cutoff Temps				More...

20. The *Economizer* menu opens.

- Select **Disabled**. (if economizer is required, see Economizer programming instructions in this document.)
- Press **Save**.



Symbols:

Duct Mount - 10K ohm Precon Type III thermistor
Taco Part #ACC-DS-8-10KP3-PB, ACC-DS12-10KP3-PB

Duct Mount - 0-10VDC Humidity Transmitter
Taco Part #ACC-DHS3-10

Duct Mount - Smoke Detector
Normally Open, Dry Contact Switch

Duct Mount - 0-10VDC Air Differential Pressure Transmitter
Taco Part #ACC-ADPT-250WC (0-2.5" WC) or ACC-ADPT-5WC (0-5" WC)

Duct Mount - Freeze Stat -
Normally Open, Dry Contact Switch

Duct Mount - Air Differential Pressure (Flow Proof) Switch
Normally Open, Dry Contact Switch, Taco Part #ACC-ADPS-12WC

Duct Mount - 0-10VDC CO2 Transmitter
Taco Part #ACC-DS-CO2

Wire Types:

Line Voltage

24VAC Low Voltage

Echelon Approved Level IV Cable
2-Wire, Twisted Pair, Non-shielded
Taco Part #WIR-022

2-Wire Low Voltage, Shielded Cable
Shield Grounded, Taco Part #WIR-018

10K Ohm 1/2 or 1/4 Watt Resistor Wire Jumper


Variable Air Volume (VAV) Staged Rooftop or Split System Up to:

- 0-10VDC Modulating Heating Valve, 0-10VDC Modulated Cooling Valve
- Fan Variable Frequency Drive

**Sensors Required – Supply Air Temp, Fan Proof, Filter Status,
Air Differential Pressure Transmitter**

Can be integrated with up to 56 Taco VAV Controllers on Taco LON Bus

Note: For Floating Point Valve Setup and Wiring, See VPU2 Application Data Sheet #505-010



VARIABLE AIR VOLUME (VAV) 4-PIPE HOT WATER, CHILLED WATER AHU OR FCU

Controlled: 0-10VDC Modulated Heating Valve, 0-10VDC Modulated Cooling Valve, Fan Variable Frequency Drive

Sensors Required: Supply Air Temp, Fan Proof, Filter Status, Air Differential Pressure Transmitter

NOTE: Instructions below assume at least 1 VAVD (up to 56) on Taco LON Bus. If none, skip steps 3 through 6.

NOTE: For Floating Point Valve Setup and Wiring, See VPU2 Application Data Sheet #505-010.

Setup Instructions

1. Press **Controllers** from main screen.
2. Select required VPU from controller list and press appropriate controller.

Controllers	15:36	PREV	HOME
ASM	OAT: 60.1°F Meter: 0 KWH		
BLMC	Demand System 0.00 %		
BZU2	Zones On: None		
BZU2-1	Zones On: None		
CCU	Sup.: 47.6°F Ret.: 59.6°F		
MPU2	Temp: 59.4°F Setp: 100.0°F		
DXU3	Temp: 78.3°F Setp: 71.0°F		
VPU	Temp: 59.8°F Setp: 55.0°F		
DXU4	Temp: 78.2°F Setp: 156.2°F		

3. Press **HVAC Setup**.

Edit Controller		15:36	PREV	HOME	
Save	Delete	Replace	Details	Upgrade	Reset
Name		VPU			
All Settings	Inputs	Outputs	Alarms		
Subsystem Status	HVAC Setup	Reset Runtimes			

4. The *HVAC Setup* menu opens. Press **Zone Members**.

VPU HVAC Setup	15:37	PREV	HOME
Backup Schedule	Runtimes And Limits	Optimum Start	Zone Members
Zone Reference			

5. The *Zone Members* menu opens.

6. Press on VAV boxes associated with MPU. Associated controllers show in RED afterward. Press **Save**.

VPU Zone Members	15:38	Save	PREV	HOME
VAVI	Master: VPU			
VAVD	Associated to : MPU2			
VAVI	Master: VPU			
VAVD	Associated to : MPU2			
VAVI	Not associated			

7. Press **Prev.** twice. From the main controller menu, press **All Settings**.

Edit Controller		15:38	PREV	HOME	
Save	Delete	Replace	Details	Upgrade	Reset
Name		VPU			
All Settings	Inputs	Outputs	Alarms		
Subsystem Status	HVAC Setup	Reset Runtimes			

8. Press **Setpoints**.

VPU Settings	15:01	Paste	PREV	HOME
Commissioning				More...
Setpoints				More...
MPU2 Setpoints				
Cooling Setpoint	15:03	Save	PREV	HOME
				55.0 °F
Heating Setpoint				80.0 °F
Supply Cool Limit				10.0 °F
Supply Heat Limit				5.0 °F

9. The *Setpoint* menu opens.

- a. Specify **Cooling Setpoint**.

- b. Specify **Heating Setpoint**.
 - c. Specify **Supply Cool Limit** (sets deviation from setpoint for alarm).
 - d. Specify **Supply Heat Limit** (sets deviation from setpoint for alarm).
 - e. Press **Save**.
10. Press **Supply Temp Reset Curve**.

VPU Settings	15:01	Paste	PREV	HOME
Commissioning			More...	
Setpoints			More...	
Supply Temp Reset Curve			More...	
Pressure Settings			More...	
MPU2 Supply Temp Reset Curve	15:06	Save	PREV	HOME
Min Differential	0.0	°F		
Max Differential	5.0	°F		
Cool Setp Low	45.0	°F		
Cool Setp High	55.0	°F		
Heat Setp Low	80.0	°F		
Heat Setp High	100.0	°F		
Next 14			Bottom	

11. The *Supply Temp Reset Curve* menu opens.
 - a. Specify **Min Differential**.
 - b. Specify **Max Differential**.
 - c. Specify **Cool Setp Low**.
 - d. Specify **Cool Setp High**.
 - e. Specify **Heat Setp Low**.
 - f. Specify **Heat Setp High**.
 - g. Press **Save**.
12. Press **Pressure Settings**.

VPU Settings	16:14	Paste	PREV	HOME
Commissioning			More...	
Setpoints			More...	
Supply Temp Reset Curve			More...	
Pressure Settings			More...	
VPU Pressure Settings	09:44	Save	PREV	HOME
Setpoint	1.80	WC		
IAQ Setpoint	1.50	WC		
Kp	5.00	%		
Ki	0.05	%		
Minimum Output	0.0	V		
Maximum Output	10.0	V		
Press Min	2.00	WC		
Press Max	5.00	WC		
Soft Start Rate	0.00	%		

13. The *Pressure Settings* menu opens.
 - a. Specify **Static Pressure Setpoint** in Inches of WC.
 - b. Specify the **IAQ Setpoint** (if applicable).
 - c. Specify **Min Output Voltage** (VDC) for VFD Drive (commonly 0-2VDC).
 - d. Specify **Max Output Voltage** (VDC) for VFD drive (commonly 10VDC).
 - e. Specify **Press Min** (Static pressure to report when the Duct SP sensor provides 0 VDC).
 - f. Specify **Press Max** (Static pressure to report when the Duct SP sensor provides 10 VDC).
 - g. Specify **Soft Start Rate**. Setting the soft start ramp rate to 0% per second or 100% per second disables soft start ramping. Soft start ramp rate slows initial fan start rate to protect equipment and ductwork.
 - h. Press **Save**.

14. Press **Modulated Cooling**.

VPU Settings	16:14	Paste	PREV	HOME
Commissioning			More...	
Setpoints			More...	
Supply Temp Reset Curve			More...	
Pressure Settings			More...	
Staged Cooling			More...	
Modulated Cooling			More...	
VPU Modulated Cooling	11:11	Save	PREV	HOME
Kp	5.00	%		
Ki	0.05	%		
Min AO Voltage	0.0	V		
Max AO Voltage	0.0	V		

15. The *Modulated Cooling* menu opens.
 - a. Specify **Min AO (Output) Voltage** (0-10VDC). 2.0VDC Shown as Example.
 - b. Specify **Max AO (Output) Voltage** (0-10VDC). 10.0VDC shown as example.
 - c. Press **Save**.

NOTE: DO NOT change factory KP/KI settings. Please review Factory KP/KI Setting White Paper # 508-001.

16. Press **Modulated Heating**.

VPU Settings	16:14	Paste	PREV	HOME
Commissioning			More...	
Setpoints			More...	
Supply Temp Reset Curve			More...	
VPU Modulated Heating	11:12	Save	PREV	HOME
Kp	5.00	%		
Ki	0.05	%		
Min AO Voltage	0.0	V		
Max AO Voltage	0.0	V		
Modulated Heating			More...	
Floating SP Heating			More...	
Next 10			Bottom	

17. The *Modulated Heating* menu opens.

- Specify **Min AO (Output) Voltage** (0-10VDC).
2.0VDC Shown as Example.
- Specify **Max AO (Output) Voltage** (0-10VDC).
10.0VDC shown as example.
- Press **Save**.

NOTE: DO NOT change factory KP/KI settings. Please review Factory KP/KI Setting White Paper # 508-001.

18. Press **Next 10**.

VPU Settings	16:14	Paste	PREV	HOME
Commissioning			More...	
Setpoints			More...	
Supply Temp Reset Curve			More...	
Pressure Settings			More...	
Staged Cooling			More...	
Modulated Cooling			More...	
Floating SP Cooling			More...	
Staged Heating			More...	
Modulated Heating			More...	
Floating SP Heating			More...	
Next 10			Bottom	


19. Press **Economizer**.

VPU Settings	16:14	Paste	PREV	HOME
Prev 10			Top	
Economizer			More...	
VPU Economizer	10:09	Save	PREV	HOME
Type	Disabled			
Setpoint	55.0	°F		
Min fresh air	10.00	%		
Kp	5.00	%		
Ki	0.05	%		
Min AO voltage	0.0	V		
Max AO voltage	10.0	V		
IAQ Sensor			More...	
Cutoff Temps			More...	

20. The *Economizer* menu opens.

- Select **Disabled**. (if economizer is required, see Economizer programming instructions in this document.)
- Press **Save**.

This page left blank intentionally



Symbols:

- | | |
|---|---|
|
Duct Mount - 10K ohm
Precon Type III thermistor
Taco Part #ACC-DS-8-10KP3-PB,
ACC-DS12-10KP3-PB |
Duct Mount - Freeze Stat -
Normally Open, Dry Contact Switch |
|
Duct Mount - 0-10VDC
Humidity Transmitter
Taco Part #ACC-DHS3-10 |
Duct Mount - Air Differential Pressure
(Flow Proof) Switch
Normally Open, Dry Contact Switch, Taco
Part #ACC-ADPS-12WC |
|
Duct Mount - Smoke Detector
Normally Open, Dry Contact Switch |
Duct Mount - 0-10VDC CO2 Transmitter
Taco Part #ACC-DS-CO2 |
|
Duct Mount - 0-10VDC Air Differential Pressure Transmitter
Taco Part #ACC-ADPT-250WC (0-2.5"WC) or ACC-ADPT-5WC (0-5"WC) | |

Wire Types:

- | | |
|--|---|
| | Line Voltage |
| | 24VAC Low Voltage |
| | Echelon Approved Level IV Cable |
| | 2-Wire, Twisted Pair, Non-shielded
Taco Part #WIR-022 |
| | 2-Wire Low Voltage, Shielded Cable
Shield Grounded, Taco Part #WIR-018 |
| | 10K Ohm 1/2 or
1/4 Watt Resistor |
| | Wire Jumper |


Adding Enthalpy Economizer

Added Module Required – Add ASM Module to network with OA Temp and Humidity Sensors

Added Sensors Required – Mixed Air Temp, Return Air Humidity

**Existing Sensors Required – Supply Air Temp, Fan Proof, Filter Status,
Air Differential Pressure Transmitter**

Can be integrated with up to 56 Taco VAV Controllers on Taco LON Bus



ADDING ENTHALPY ECONOMIZER

Controlled: 0-10VDC Modulated or 2-pos Economizer Damper Actuator

Added Module Required: Add ASM Module to network with OA Temp and Humidity Sensors

Added Sensors Required: Mixed Air Temp, Return Air Humidity

Existing Sensors Required: Return Air Temp, Supply Air Temp, Fan Proof, Filter Status

Setup Instructions

1. Press **Controllers** from main screen.
2. Select required VPU from controller list and press appropriate controller.
3. Press **All Settings**.
4. Press **Next 14**.
5. Press **Economizer**.

VPU Settings	16:14	Paste	PREV	HOME
Prev 10		Top		
Economizer		More...		
Free Cooling		More...		
VPU Economizer	10:09	Save	PREV	HOME
Type	Disabled ▾			
Setpoint	55.0 °F			
Min fresh air	10.00 %			
Kp	5.00 %			
Ki	0.05 %			
Min AO voltage	0.0 V			
Max AO voltage	10.0 V			
IAQ Sensor	More...			
Cutoff Temps	More...			

6. The *Economizer* menu opens.

a. Select **Type** of economizer control:

- 2 st (2 position), Unocc ON
- 2 st (2 position), Unocc OFF
- Mod (modulating), Unocc ON
- Mod (modulating), Unocc OFF

NOTE: Unocc ON/OFF specifies whether you want the economizer enabled (ON) or disabled(OFF) during the unoccupied time periods.

b. Select economizer **setpoint**, which specifies the outside air temperature at which the economizer is enabled.

c. Select **Min Fresh Air %**. The minimum required damper position for ventilation specified.

d. Select **Min AO** (Output) Voltage (0-10VDC) for damper actuator. 0.0VDC Shown as Example.

e. Select **Max AO** (Output) Voltage (0-10VDC) for damper actuator. 10.0VDC shown as example. If a reverse action damper is used then reverse the min and max voltages.

f. Press **Save**.

g. Note: DO NOT change factory KP/KI settings. Please review Factory KP/KI Setting White Paper # 508-001.

7. Press **Free Cooling**.

VPU Settings	16:14	Paste	PREV	HOME
Prev 10		Top		
Economizer		More...		
Free Cooling		More...		
VPU Free Cooling	11:27	Save	PREV	HOME
Type	Drybulb Temp. ▾			
Enthalpy offset	5.0 BTU/lb			
Dry Bulb offset	5.0 °F			
IAQ Mode	Digital			
IAQ Settings	More...			
IAQ Sensor	More...			
Cutoff Temps	More...			

8.8. The *Free Cooling* menu opens.

a. Select **Type** of economizer control:

- Return Air Humidity (Enthalpy)
- Global Humidity (not used)
- Dry Bulb

b. Select **Enthalpy Offset** (Humidity Ratio) in BTU/lb

c. Select **Dry Bulb Offset** in degrees.

d. Press **Save**.

e. Note: Setting as per engineered documents. If specific settings are not known, leave at factory defaults shown above.


9. Press **Next 4**.

10. Press **Cutoff Temps**.

VPU Settings	16:14	Paste	PREV	HOME
Prev 10			Top	
Economizer			More...	
Free Cooling			More...	
Dehumidification			More...	
VPU Cutoff Temps	11:28	Save	PREV	HOME
Max OAT Heat	65.0	°F		
Min OAT Cool	55.0	°F		
Max OAT Econ	65.0	°F		
Min OAT Econ	45.0	°F		
SAT Cooling Limit	55.0	°F		
Cutoff Temps			More...	

11. The *Cutoff Temps* menu opens.

- Specify **Max OAT Heating**.
- Specify **Min OAT Cooling**.
- Specify **Max OAT Economizer**.
- Specify **SAT Cooling Limit**.
- Press **Save**.



Symbols:


- Duct Mount - 10K ohm Precon Type III thermistor
Taco Part #ACC-DS-8-10KP3-PB, ACC-DS12-10KP3-PB
- Duct Mount - 0-10VDC Humidity Transmitter
Taco Part #ACC-DHS3-10
- Duct Mount - Smoke Detector
Normally Open, Dry Contact Switch
- Duct Mount - 0-10VDC Air Differential Pressure Transmitter
Taco Part #ACC-ADPT-250WC (0-2.5"WC) or ACC-ADPT-5WC (0-5"WC)

- Duct Mount - Freeze Stat - Normally Open, Dry Contact Switch
- Duct Mount - Air Differential Pressure (Flow Proof) Switch
Normally Open, Dry Contact Switch, Taco Part #ACC-ADPS-12WC
- Duct Mount - 0-10VDC CO2 Transmitter
Taco Part #ACC-DS-CO2

Wire Types:

- Line Voltage
- 24VAC Low Voltage
- Echelon Approved Level IV Cable
2-Wire, Twisted Pair, Non-shielded
Taco Part #WIR-022
- 2-Wire Low Voltage, Shielded Cable
Shield Grounded, Taco Part #WIR-018
- 10K Ohm $\frac{1}{2}$ or $\frac{1}{4}$ Watt Resistor
- Wire Jumper

Adding Demand Controlled Ventilation (CO2)
Added Sensors Required – Duct Mount (Taco Part #ACC-DS-CO2)
Existing Sensors Required – Supply Air Temp, Fan Proof, Filter Status,
Air Differential Pressure Transmitter
Can be integrated with up to 56 Taco VAV Controllers on Taco LON Bus



ADDING DEMAND CONTROLLED VENTILATION (CO2)

Controlled: 0-10VDC Modulated or 2-pos Economizer Damper Actuator based on space or return duct CO2

Added Sensors Required: Duct Mount (Taco Part #ACC-DS-CO2) or Wall Mount (Taco Part #ACC-RS-CO2) CO2 Sensor

Existing Sensors Required: Return Air Temp, Supply Air Temp, Fan Proof, Filter Status

1. Press **Controllers** from main screen.
2. Select required VPU from controller list and press appropriate controller.
3. Press **All Settings**.
4. Press **Next 10**.
5. Press **IAQ Mode**.

VPU Settings	16:14	Paste	PREV	HOME
Prev 10			Top	
Economizer			More...	
Free Cooling			More...	
VPU IAQ Mode	11:33	Save	PREV	HOME

IAQ Mode

Digital ▾	
IAQ Mode	Digital
IAQ Settings	More...
IAQ Sensor	More...
Cutoff Temps	More...

6. The *IAQ Mode* menu opens.
7. Select IAQ sensor input mode:
 - Digital = Open/close switch sensor
 - Analog = 0-10VDC Sensor (shown)
8. Press **Save**.

9. Press **IAQ Settings**.

VPU Settings	16:14	Paste	PREV	HOME
Prev 10			Top	
Economizer			More...	
Free Cooling			More...	
Dehumidification			More...	
VPU IAQ Settings	11:34	Save	PREV	HOME
IAQ Delay Time	0	Min		
Temp Reset Limit	14.0	°F		
Deadband	100	ppm		
IAQ Settings			More...	
IAQ Sensor			More...	
Cutoff Temps			More...	

10. The *IAQ Settings* menu opens.

- Select **IAQ Delay Time** before response to IAQ demand.
- Select **Temp Reset Limit** to allow +/- deviation from space temperature setpoint in order to satisfy IAQ demand.
- Set Deadband in PPM.
- Press **Save**.

11. Press **IAQ Sensor**.

VPU Settings	16:14	Paste	PREV	HOME
Prev 10			Top	
Economizer			More...	
Free Cooling			More...	
Dehumidification			More...	
VPU IAQ Sensor	11:34	Save	PREV	HOME
Min	0	ppm		
Max	0	ppm		
Setpoint	0	ppm		
Offset	0	ppm		
IAQ Sensor			More...	
Cutoff Temps			More...	

12. The *IAQ Sensor* menu opens.

- Select **Min** PPM.
- Select **Max** PPM.
- Select **Setpoint** PPM.
- Select **Offset** (calibration) PPM.
- Press **Save**.


TROUBLESHOOTING

Diagnostic LEDs

The controller has 3 LED indicators. These indicators can aid in troubleshooting equipment operation problems. The following table lists the functions of the controller's LEDs in the order they appear from left to right on the unit.

LED	Indication
Status	<ul style="list-style-type: none"> – Solid green when running and configured by an LCI (networking) – Flashing green when running and NOT configured by an LCI (stand-alone) – Solid red when a fault condition exists (control shut down) – Blinking Red - the controller has a device failure – Solid Amber - The controller has not received a LCI ping message in over 10 minutes and is part of a network.
Network	<ul style="list-style-type: none"> – Yellow while the controller is transmitting data onto the FTT-10A network – Green when there is network activity – Off when there is no network activity
Service	<ul style="list-style-type: none"> – Illuminated when the service pin is depressed or when a controller gets configured by the LCI.

Figure 2: VPU2 Controller LEDs



Troubleshooting Tips

The table below provides solution to some common problems you may encounter.

Problem	Solution
Controller is not running and Status LED is not illuminated.	No power to controller. Verify the voltage on the controller's power connector (24 VAC).
How do I reset the controller?	The controller can be reset by the LCI, or you can cycle power to the controller. Refer to the LCI documentation for more information on resetting the controller using the LCI.
Can my iWorx® system contain multiple VPU2 controllers?	Yes, provided that you do not exceed the maximum number of controllers that can be handled by the Local Control Interface (LCI).
Thermistor readings fluctuate rapidly, sometimes by several degrees.	The controller is not properly grounded. The controller's ground (GND) pin (T40) must be connected to earth ground. Also ensure that the controller's digital inputs are dry contacts and that no voltage is being applied or switched to the inputs.
How do I associate my VAVI controllers with the VPU2?	Use the VPU2's grouping mechanism, specifically Zone Members on the <i>HVAC Setup</i> screen of the LCI.

Getting Help

Components within an iWorx® VPU2 controller cannot be field repaired. If there is a problem with a controller, follow the steps below before contacting your local TES representative or TES technical service.

1. Make sure controllers are connected and communicating to desired devices.
2. Record precise hardware setup indicating the following:
 - Version numbers of applications software.
 - Controller firmware version number.
 - A complete description of difficulties encountered.

REPRESENTATIONS AND WARRANTIES

This Document is subject to change from time to time at the sole discretion of Taco Electronic Solutions, Inc. All updates to the Document are available at www.taco-hvac.com. When installing this product, it is the reader's responsibility to ensure that the latest version of the Document is being used.

iWorx® products shall only be used for the applications identified in the product specifications and for no other purposes. For example, iWorx® products are not intended for use to support fire suppression systems, life support systems, critical care applications, commercial aviation, nuclear facilities or any other applications where product failure could lead to injury to person, loss of life, or catastrophic property damage and should not be used for such purposes.

Taco Electronic Solutions, Inc. will not be responsible for any product or part not installed or operated in conformity with the Document and instructions or which has been subject to accident, disaster, neglect, misuse, misapplication, inadequate operating environment, repair, attempted repair, modification or alteration, or other abuse. For further information, please refer to the last page of this Document for the company's Limited Warranty Statement, which is also issued with the product or available at www.taco-hvac.com.

APPLICABLE DOCUMENTATION

See the table below for additional documentation that may be applicable to this controller.

Description	Audience	Purpose
<i>iWorx® VPU2 Application Guide</i> , Document No. 505-010	<ul style="list-style-type: none"> – Application Engineers – Installers – Service Personnel – Start-up Technicians – End user 	Provides instructions for setting up and using the iWorx® VPU2 controller.
<i>iWorx® LCI Application Guide</i> , Document No. 505-002	<ul style="list-style-type: none"> – Application Engineers – Installers – Service Personnel – Start-up Technicians – End user 	Provides instructions for setting up and using the iWorx® Local Control Interface.
<i>iWorx® LCI3 Application Guide</i> , Document No. 505-050	<ul style="list-style-type: none"> – Application Engineers – Installers – Service Personnel – Start-up Technicians – End user 	Provides instructions for setting up and using the iWorx® VAV Series controller.
<i>iWorx® VAV Series Application Guide</i> , Document No. 505-011	<ul style="list-style-type: none"> – Application Engineers – Installers – Service Personnel – Start-up Technicians – End user 	Provides instructions for setting up and using the iWorx® VAV Series controller.
http://www.iWorxWizard.com	<ul style="list-style-type: none"> – Application Engineers – Wholesalers – Contractors 	An on-line configuration and submittal package generator based on user input. Automatically generates bill of materials, sequence of operations, flow diagrams, wiring diagrams, points and specifications.
Additional Documentation	<i>LonWorks FTT-10A Free Topology Transceiver User's Guide</i> , published by Echelon Corporation. It provides specifications and user instructions for the FTT-10A Free Topology Transceiver. See also: www.echelon.com/support/documentation/manuals/transceivers .	

Notes:

LIMITED WARRANTY STATEMENT

Taco Electronic Solutions, Inc. (TES) will repair or replace without charge (at the company's option) any product or part which is proven defective under normal use within one (1) year from the date of start-up or one (1) year and six (6) months from date of shipment (whichever occurs first).

In order to obtain service under this warranty, it is the responsibility of the purchaser to promptly notify the local TES stocking distributor or TES in writing and promptly deliver the subject product or part, delivery prepaid, to the stocking distributor. For assistance on warranty returns, the purchaser may either contact the local TES stocking distributor or TES. If the subject product or part contains no defect as covered in this warranty, the purchaser will be billed for parts and labor charges in effect at time of factory examination and repair.

Any TES product or part not installed or operated in conformity with TES instructions or which has been subject to accident, disaster, neglect, misuse, misapplication, inadequate operating environment, repair, attempted repair, modification or alteration, or other abuse, will not be covered by this warranty.

TES products are not intended for use to support fire suppression systems, life support systems, critical care applications, commercial aviation, nuclear facilities or any other applications where product failure could lead to injury to person, loss of life, or catastrophic property damage and should not be sold for such purposes.

If in doubt as to whether a particular product is suitable for use with a TES product or part, or for any application restrictions, consult the applicable TES instruction sheets or in the U.S. contact TES at 401-942-8000 and in Canada contact Taco (Canada) Limited at 905-564-9422.

TES reserves the right to provide replacement products and parts which are substantially similar in design and functionally equivalent to the defective product or part. TES reserves the right to make changes in details of design, construction, or arrangement of materials of its products without notification.

TES OFFERS THIS WARRANTY IN LIEU OF ALL OTHER EXPRESS WARRANTIES. ANY WARRANTY IMPLIED BY LAW INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS IS IN EFFECT ONLY FOR THE

DURATION OF THE EXPRESS WARRANTY SET FORTH IN THE FIRST PARAGRAPH ABOVE.

THE ABOVE WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR STATUTORY, OR ANY OTHER WARRANTY OBLIGATION ON THE PART OF TES.

TES WILL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF ITS PRODUCTS OR ANY INCIDENTAL COSTS OF REMOVING OR REPLACING DEFECTIVE PRODUCTS.

This warranty gives the purchaser specific rights, and the purchaser may have other rights which vary from state to state. Some states do not allow limitations on how long an implied warranty lasts or on the exclusion of incidental or consequential damages, so these limitations or exclusions may not apply to you.

CONTROLS MADE EASY®

Taco Electronic Solutions, Inc., 1160 Cranston Street, Cranston, RI 02920
Telephone: (401) 942-8000 FAX: (401) 942-2360.

Taco (Canada), Ltd., 8450 Lawson Road, Unit #3, Milton, Ontario L9T 0J8.
Telephone: 905/564-9422. FAX: 905/564-9436.

Taco Electronic Solutions, Inc. is a subsidiary of Taco, Inc.
Visit our web site at: <http://www.taco-hvac.com>