

Boiler Feed Valves (Pressure Reducing Valves) Models 329, 329-T, 329-H, 335, 335U-050-C, 335U-050-T, 335U-050-H, 335U-075-C, 335U-075-T

Dual Controls Models 334, 334-T and 334-H

SUPERSEDES: November 6, 2017

EFFECTIVE: February 25, 2019

Plant I.D. 001-924

RATINGS:

Boiler Feed Valves (Reducing Valves):

Maximum Fluid Temperature	212°F (100°C)
Maximum Supply Side Pressure	100 psi (689 kpa)
Setting Range	10-25 psi (69-172 kpa)
Factory Setting of System Side	12 psi (83 kpa)

Dual Controls:

Maximum Fluid Temperature	212°F (100°C)
Maximum Supply Side Pressure	100 psi (689 kpa)
Relief Valve Set to Release at	30 psi (207 kpa)



Caution: Boiler Feed Valves and Dual Controls should only be installed by qualified heating professionals. Consult local authorities for any code requirements in your area.

DESCRIPTION:

The Boiler Feed Valves are adjustable pressure reducing valves that automatically maintain system pressure. They are equipped with a FAST FILL lever that can be used to override automatic pressure regulation during purging.

Models	Body	Inlet	Outlet
329	Cast Iron	1/2" Union SWT	1/2" NPT
329-T	Cast Iron	1/2" Union NPT	1/2" NPT
329-H	Cast Iron	1/2" Union Press	1/2" NPT
335	Brass	3/4" NPT	3/4" NPT
335U-050-C	Brass	1/2" Union SWT	1/2" NPT
335U-050-T	Brass	1/2" Union NPT	1/2" NPT
335U-050-H	Brass	1/2" Union Press	1/2" NPT
335U-075-C	Brass	3/4" Union SWT	3/4" NPT
335U-075-T	Brass	3/4" Union NPT	3/4" NPT

The Dual Control consists of a 329 Boiler Feed Valve with an in-line pressure relief valve connected at its outlet end.


Models	Body	Inlet	Outlet
334	Cast Iron	1/2" Union SWT	1/2" NPT
334-T	Cast Iron	1/2" Union NPT	1/2" NPT
334-H	Cast Iron	1/2" Union Press	1/2" NPT

INSTALLATION:

1. Install the Boiler Feed Valve or the Dual Control in a horizontal position in the cold water supply pipe to the boiler.
2. Install a shut-off valve on the upstream side of the Boiler

Feed Valve. This valve, provided for isolation purposes during maintenance, must be open at all times during operation so that the Boiler Feed Valve can maintain pressure automatically.

3. Flush out the supply pipe to clear it of chips, scale, dirt, etc. before connecting it to the inlet of the Boiler Feed Valve.
4. Connect a pipe from the bottom "DRAIN" connection of the Relief Valve in the Dual Control. Direct it to some convenient open drain, such as a floor drain or set tubs. Always obey local regulations. DO NOT install a valve of any kind in the drain pipe. The pipe must always pitch down from the valve, with no part of it above the valve, and be no smaller in size than the valve drain connection size.




OPERATION:

1. To fill the system, open the shut-off valve upstream of the Boiler Feed Valve. This valve must always be kept open when the system is in operation.
2. The FAST FILL lever must be pushed all the way over to the side of the cover slot, over the "A" on the cover flange for AUTOMATIC operation. The supply water will flow into the system until it is full and under pressure.
3. The Taco Boiler Feed Valves have such a high flow capacity that the FAST FILL feature is not usually needed during filling. It is supplied for use during purging of the system. By moving the lever down and to the side over the "O" on the flange of the cover (OVERRIDE position), the valve will be held open, overcoming the closing action of pressure increases against its diaphragm.
4. After filling and purging, the FAST FILL lever must be placed at the AUTOMATIC ("A" side) position. Under system pressure the lever will move up and be secured in the notch. The lever should not be moved during system operation. This position allows the valve to maintain normal pressure in the system automatically.



WARNING: Using the FAST FILL feature with the purge valve closed can cause system over pressurization. This may cause the pressure relief to discharge extremely hot water, resulting in personal injury or death and damage to other system components or water damage to other property. Care must be taken to prevent over pressurizing the system.

5. The Boiler Feed Valve is factory set to deliver water to the boiler at 12 psi. To determine the required pressure if the factory setting is not sufficient to lift the water to the highest radiation, calculate the number of feet from the regulator to the top of the highest radiation. Multiply this by .43 and add 3 psi. This is the pressure needed to raise the water to the highest radiation and keep it under sufficient pressure. To increase the valve setting, loosen the locking nut on the adjusting screw at the top of the valve. Now turn the adjusting screw in (clockwise) slowly until the gauge indicates the pressure calculated. Then lock the adjusting screw with its locking nut.
6. The pressure relief valve of the Dual Control is non-adjustable and is set to relieve at 30 psi.



LIMITED WARRANTY STATEMENT

Taco, Inc. will repair or replace without charge (at the company's option) any product or part which is proven defective under normal use within one (1) year from the date code.

In order to obtain service under this warranty, it is the responsibility of the purchaser to promptly notify the local Taco stocking distributor or Taco in writing and promptly deliver the subject product or part, delivery prepaid, to the stocking distributor. For assistance on warranty returns, the purchaser may either contact the local Taco stocking distributor or Taco. If the subject product or part contains no defect as covered in this warranty, the purchaser will be billed for parts and labor charges in effect at time of factory examination and repair.

Any Taco product or part not installed or operated in conformity with Taco instructions or which has been subject to misuse, misapplication, the addition of petroleum-based fluids or certain chemical additives to the systems, or other abuse, will not be covered by this warranty.

If in doubt as to whether a particular substance is suitable for use with a Taco product or part, or for any application restrictions, consult the applicable Taco instruction sheets or contact Taco at [401-942-8000].

Taco reserves the right to provide replacement products and parts which are substantially similar in design and functionally equivalent to the

defective product or part. Taco reserves the right to make changes in details of design, construction, or arrangement of materials of its products without notification.

TACO OFFERS THIS WARRANTY IN LIEU OF ALL OTHER EXPRESS WARRANTIES. ANY WARRANTY IMPLIED BY LAW INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS IS IN EFFECT ONLY FOR THE DURATION OF THE EXPRESS WARRANTY SET FORTH IN THE FIRST PARAGRAPH ABOVE.

THE ABOVE WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR STATUTORY, OR ANY OTHER WARRANTY OBLIGATION ON THE PART OF TACO.

TACO WILL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF ITS PRODUCTS OR ANY INCIDENTAL COSTS OF REMOVING OR REPLACING DEFECTIVE PRODUCTS.

This warranty gives the purchaser specific rights, and the purchaser may have other rights which vary from state to state. Some states do not allow limitations on how long an implied warranty lasts or on the exclusion of incidental or consequential damages, so these limitations or exclusions may not apply to you.



A Taco Family Company

Taco, Inc., 1160 Cranston Street, Cranston, RI 02920 | Tel: (401) 942-8000 | FAX: (401) 942-2360

Taco (Canada), Ltd., 8450 Lawson Road, Suite #3, Milton, Ontario L9T 0J8 | Tel: (905) 564-9422 | FAX: (905) 564-9436

Visit our web site: www.TacoComfort.com | Printed in USA | ©2019 Taco, Inc.

